



## **ALIPHATIC/AROMATIC FLEXCOAT**

### **Installation Instructions**

#### **Materials**

- Aliphatic or Aromatic FlexCoat in 5 gallon pail

#### **Mixing and Installing FlexCoat**

1. Thoroughly mix supplied FlexCoat. Dip a nap roller into the mixture using a painter's screen to wipe off excess coating from roller. Apply with roller to surface of area to be coated. Roll even until entire area is covered. This application should be applied very thin.
  - a. One 5-gallon pail of FlexCoat yields approximately 500 sq. ft. of coverage over a porous surface.
  - b. One 5-gallon pail of FlexCoat yields approximately 1000 sq. ft. of coverage over a solid surface.
2. Allow to cure for 24 hours or until dry to the touch.